


GoDEX DT4X INVENTORY PRINTER MANUAL

Here are what you will receive:









Step 2:

Turn on → Hold the light button until light blink → Release and click 1 time. It will print out the Calibration and we can check the IP address.

Step 3:

Open Inventory App → Sign in → Select item → (scroll down) "Connect printer IP" → Update to check if connect successful → Print.

